

Fitting Instructions

When connecting Oil/Air Line to Gauge

Fit Spanner onto flat part of Brass Thread.



Make sure that silver Olive is in correct position, with cone facing away from gauge.

Push Oil/Air Line into Gauge and tighten by hand first.

Put Second Spanner on nut and tighten until Oil/Air line cannot be removed.

